

INSTALLATION INSTRUCTIONS

Shower Trays & Wall Panels

IMPORTANT

Please check your SMO™ shower tray/panel for any transit damage, correct size and colour and any manufacture defect. Fitting of the product is acceptance of its specification and quality.


Your tray or panel should preferably be stored flat, if space is not available stand as straight as possible horizontally (see pictures below).

NOTE - ALL TRAYS

It is imperative water out flow is tested before any tiling is carried out and installer and client are satisfied waste water is draining away.

No liability will be accepted by Ambiance Bain after this stage if there are any issues with outflow.

Recommended Storage



CUTTING

Measure twice, cut once!

Cut from finished side, cover area with protective tape to avoid marking surface and avoid shards. A fine-toothed blade is best for cutting the SMO™, either a hand saw or electric jigsaw. Alternatively, a diamond tipped circular blade. Experience tells us cutting by hand gives a neater cut.

SEALANT

Ensure a good quality sanitary grade silicone is used for sealing joints.

ADHESIVE

We recommend a good quality adhesive-based silicone is used for fixing wall panels. Alternatively, flexible tile adhesive can also be used.

MAINTENANCE

Most household cleaning fluids can be used.

Avoid:

Water temperature over 60 degrees, abrasive cleaners, steel wool, rough sponges and ammonia based products (also, be careful with hair dye).

If accidentally scratched or chipped, repair and polish kits are available. Please consult your Ambiance Bain dealer.



INSTALLATION INSTRUCTIONS



Waste outlet - refer to manufacturers instructions.

PREPARATION (All Trays)

Place the tray in situ and mark around the tray as shown.

Prepare a rigid base using 18mm marine plywood. This can be overlaid over the existing floor boards, laid directly onto floor joists or if required for the tray to sit lower the base can be cut and laid at joist level. Bear in mind waste outlet position and running of waste pipe. We recommend a single outlet pipe of 50mm diameter to maximise water outflow.


If the tray is required to sit flush with the floor tiles it is up to the installer to adjust levels to suit.



FITTING

ALTIMA TRAY

Cover base with a level solid bed of 5:1 mix sand cement or cement-based floor tile adhesive. Gently lower the tray into place and apply pressure to bed it down and ensure it is completely level before allowing to set for 24 hours. Once in place seal edges to wall using silicone. Connect waste and test outflow.




INSTALLATION INSTRUCTIONS

FITTING




ZBSR40

Cover outside perimeter of tray area with 5:1 mix sand cement and surround central waste outlet with a raised ring of the same mix. Gently lower the tray into place and apply pressure to bed it down and ensure it is completely level before allowing to set for 24 hours. Connect waste and test outflow. Once in place seal edges to wall using silicone.



ZBSI


1. Fix legs to underside of tray.
2. Place the tray into position and adjust leg levels before final fixing.
3. It is recommended to install an outlying support belt maximum 50mm thick to sit the edges of the tray onto (lightweight tiling board is ideal). Ensure tray is stable and level. Outside supports are best installed after leg adjustment and levels are set. Silicone can be used to hold the tiling boards in place.
4. Carefully place tray into position, connect waste and test outflow.
5. Once in place seal edges to wall using silicone.



INSTALLATION INSTRUCTIONS

OPTIONAL SMO™ PLINTH FOR ZBSI

Tray sides can be either tiled onto tiling support board or an optional made to measure SMO™ plinth (20mm) can be used.




INSTALLATION INSTRUCTIONS

SMO™ WALL PANELS (ZPAN & ZPDEC) IMPORTANT

Please check your SMO™ wall panel for any transit damage, correct size and colour and any manufacture defect. Fitting of the product is acceptance of its specification and quality.

Your panel should preferably be stored flat, if space is not available, stand as straight as possible horizontally. See pictures for details.

Recommended Storage



Storage in horizontal upright position

Flat storage recommended

CUTTING

Measure twice, cut once!

Cut from finished side, cover area with protective tape to avoid marking surface and avoid shards. A fine-toothed blade is best for cutting the SMO™, either a hand saw or electric jigsaw. Alternatively, a diamond tipped circular blade.

Experience tells us cutting by hand gives a neater cut.

For drilling holes, ensure the area to be cut is protected with tape to avoid marking the surface and avoid shards. Use a standard hold cutter of the correct size to drill through for supply pipes. For larger recessed type shower valves, a fine-toothed jigsaw should be used.

SEALANT

Ensure a good quality sanitary grade silicone is used for sealing joints.

ADHESIVE

We recommend a good quality adhesive-based silicone is used for fixing wall panels. Alternatively, flexible tile adhesive can also be used.

MAINTENANCE

Most household cleaning fluids can be used.

Avoid:

Water temperature over 60 degrees, abrasive cleaners, steel wool, rough sponges and ammonia based products (also, be careful with hair dye).

If accidentally scratched or chipped, repair and polish kits are available. Please consult your Ambiance Bain dealer.

PREPARATION

The surface behind the panels must be of good construction and if necessary a waterproof sealant applied prior to fixing any panels.

INSTALLATION INSTRUCTIONS

INSTALLATION

We recommend to dry fit the panels and mark out any holes or cuts that need to be made.

Apply adhesive to wall in vertical lines as shown, no more than 200mm apart and around the perimeter edge.

Carefully set panel in place and push onto adhesive. Once all panels are installed, we recommend putting supports in place for 24 hours until the adhesive has cured.

